

Wiring Diagrams


Double Intermediate Switch with Orienting Light




Rocker Push-button




Rocker Push-button (NO + NC)




Rocker Push-button with Orienting Light 250 V ~



Rocker Push-button with Orienting Light 12 V ⎓



Rocker Push-button with Independent Pilot Lamp



Rocker Push-button with Identification 250 V ~

